


HOW TO BUILD A CRITTER BOT


AAA Version 1.0

PART A: CREATE YOUR ROBOT'S TORSO


A 1 Decorate a "Robot Torso" shape. Cut out with scissors.



A 2 Remove the paper backing from the stickers on the mini cup.



A 3 Wrap the "Robot Torso" around the mini cup. Tape down the ends.




PART B: CREATE YOUR ROBOT'S HEAD

B 1 Decorate a "Robot Head" shape. Cut out with scissors.




B 2 Remove the paper backing from 1 side of the double-stick foam.




B 3 Attach the double-stick foam to the **back** of your robot's head.

B 4 Remove the paper backing from side 2 of the double-stick foam. Attach your robot's head to the cup.





B 5 Use craft supplies to give your robot arms, feet, a tail, and clothes.



PART C: MAKE YOUR ROBOT MOVE


C 1 Place a piece of double-stick foam on the bottom of the vibration motor. Attach the vibration motor to the top of the mini cup. Make sure the eccentric wheel of the motor can freely spin without hitting the cup.



C 2 Insert an AAA battery into the battery holder. Match up the red wire to the positive (+) end of the battery and the black wire to the negative (-) end of the battery.




C 3 Place a piece of double-stick foam on the back of the battery holder. Attach the battery holder to the side of the cup.




PART D: MAKE A SWITCH

D 1 Insert the red wire of the motor into the red wire of the battery holder.




D 2 Insert the black wire of the motor into the black wire of the battery holder. You should feel your robot move!



D 3 To turn off your robot, unplug the black wires.

To turn your robot back **ON**, repeat step **D 2** above.



HOORAY! YOU'VE FINISHED BUILDING YOUR CRITTERBOT!



Attribution-NonCommercial-ShareAlike
CC BY-NC-SA



SIDE 2